

CREATE  
YOUR STYLE  
with SWAROVSKI ELEMENTS



CREATE YOUR STYLE  
MINI PROJECTS

# INNOVATIONS

SPRING/SUMMER 2013



CREATE  
YOUR STYLE  
with SWAROVSKI ELEMENTS



MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# EGYPTIAN GEM COLLAR

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	6 pcs.	6 mm	Crystal Ivory Pearl	001 708
Crystal Pearls	5810	6 pcs.	6 mm	Crystal Turquoise Pearl	001 709
Crystal Pearls	5810	4 pcs.	6 mm	Crystal Jade Pearl	001 715
Crystal Pearls	5810	6 pcs.	6 mm	Crystal Red Coral Pearl	001 718
Crystal Pearls	5810	6 pcs.	6 mm	Crystal Dark Lapis Pearl	001 719
Crystal Pearls	5810	51 pcs.	10 mm	Crystal Ivory Pearl	001 708
Crystal Pearls	5810	39 pcs.	10 mm	Crystal Turquoise Pearl	001 709
Crystal Pearls	5810	43 pcs.	10 mm	Crystal Jade Pearl	001 715
Crystal Pearls	5810	47 pcs.	10 mm	Crystal Red Coral Pearl	001 718
Crystal Pearls	5810	35 pcs.	10 mm	Crystal Dark Lapis Pearl	001 719

Supplies: 2 6 mm TierraCast jump Ring 01-0025-09  
8 1" ball head pins  
10 3mm crimp covers  
6" of heavy link chain

120" Beadalon 0.018 stringing wire  
10 2x2 crimp beads  
2 5 hole spacer bars  
1 large lobster clasp

## Instructions

STEP 1: Cut one 18" piece of stringing wire. Secure one end (i.e. tape). String on one Crystal Pearl art. 5810 6mm Crystal Dark Lapis Pearl, 35 10mm Crystal Dark Lapis Pearls and one 6mm Crystal Dark Lapis Pearl. Secure open end. Set aside.

[Continuation on next page](#)

"Egyptian Gem Collar", page 2

- STEP 2: Cut one 20" piece of stringing wire. Secure one end. String on one 6mm Crystal Turquoise Pearl, 39 10mm Crystal Turquoise Pearls and one 6mm Crystal Turquoise Pearl. Secure open end. Set aside.
- STEP 3: Cut one 22" piece of stringing wire. Secure one end. String on one 6mm Crystal Jade Pearl, 43 10mm Crystal Jade Pearls and one 6mm Crystal Jade Pearl. Secure open end. Set aside.
- STEP 4: Cut one 24" piece of stringing wire. Secure one end. String on one 6mm Crystal Red Coral Pearl, 47 10mm Crystal Red Coral Pearls and one 6mm Crystal Red Coral Pearl. Secure open end. Set aside.
- STEP 5: Cut one 26" piece of stringing wire. Secure one end. String on one 6mm Crystal Ivory Pearl, 51 10mm Crystal Ivory Pearls and one 6mm Crystal Ivory Pearl. Secure open end. Set aside.
- STEP 6: Using one balled headpin, slip on one 6mm Crystal Dark Lapis Pearl. Create a simple loop. Repeat once.
- STEP 7: Repeat step 6 for 2 6mm Crystal Turquoise Pearls, 2 6mm Crystal Jade Pearls, 2 6mm Crystal Red Coral Pearls and 2 6mm Crystal Ivory Pearls. Set aside.
- STEP 8: Cut the 6" heavy link chain in half.
- STEP 9: Using the strand from step 1, slide one end of the stringing wire into the outside hole of one spacer bar, slide on one 6mm Crystal Dark Lapis Pearl and crimp to the loop on the wired bead from step 6. Cover crimp with a crimp cover. Repeat this step for the other end of the wire using the corresponding hole on the second spacer bar.
- STEP 10: Using the strand from step 2, slide one end of the stringing wire into the 2nd hole on one spacer bar, slide on one 6mm Crystal Turquoise Pearl and crimp to the loop on a corresponding wired bead from step 7. Cover crimp with a crimp cover. Repeat this step for the other end of the wire using the corresponding hole on the second spacer bar. (Note: the bead strands should be sitting side-by-side.)
- STEP 11: Using the strand from step 3, slide one end of the stringing wire into the 3rd hole on one spacer bar, slide on one 6mm Crystal Jade Pearl and crimp to the last link on one 3" piece of chain. Cover crimp with a crimp cover. Repeat this step for the other end of the wire using the corresponding hole on the second spacer bar and crimping to the second 3" piece of chain. (Note: the bead strands should be sitting side-by-side.)
- STEP 12: Using the strand from step 4, slide one end of the stringing wire into the 4th hole on one spacer bar, slide on one 6mm Crystal Red Coral Pearl and crimp to the loop on a corresponding wired bead from step 7. Cover crimp with a crimp cover. Repeat this step for the other end of the wire using the corresponding hole on the second spacer bar. (Note: the bead strands should be sitting side-by-side.)
- STEP 13: Using the strand from step 5, slide one end of the stringing wire into the last remaining hole on one spacer bar, slide on one 6mm Crystal Ivory Pearl and crimp to the loop on a corresponding wired bead from step 7. Cover crimp with a crimp cover. Repeat this step for the other end of the wire using the last remaining hole on the second spacer bar. (Note: the bead strands should be sitting side-by-side.)
- STEP 14: Open one jump ring and attach to open end of chain on one side, close jump ring.
- STEP 15: Open one jump ring and slip on lobster and attach to open end of chain on the second piece. Close ring.

# CREATE YOUR STYLE

with SWAROVSKI ELEMENTS

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

## QUINTET OF CRYSTAL PEARL GEMS EARRINGS



### Materials

#### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5000 (Round)	2 pcs.	4 mm	Pacific Opal	390
Beads	5040 (Briolette)	2 pcs.	8 mm	Crystal Metallic Light Gold 2x	001 MLG2
Beads	5328 (XILION)	2 pcs.	4 mm	Turquoise	267
Beads	5328 (XILION)	2 pcs.	4 mm	Crystal Metallic Light Gold 2x	001 MLG2
Crystal Pearls	5810	20 pcs.	4 mm	Crystal Dark Lapis Pearl	001 719
Crystal Pearls	5810	54 pcs.	4 mm	Crystal Red Coral Pearl	001 718
Crystal Pearls	5810	2 pcs.	6 mm	Crystal Ivory Pearl	001 708
Crystal Pearls	5810	2 pcs.	10 mm	Crystal Ivory Pearl	001 708
Crystal Pearls	5810	2 pcs.	10 mm	Crystal Jade Pearl	001 715
Crystal Pearls	5811	2 pcs.	16 mm	Crystal Ivory Pearl	001 708
Crystal Pearls	5811	2 pcs.	16 mm	Crystal Turquoise Pearl	001 709

Supplies: 4 Silver earwires TierraCast 90-1120-00  
 2 Nisshu Charms TierraCast 94-2025-12  
 18" 20 gauge silver Artistic Wire  
 2 Copper Headpin TierraCast 01-0028-08  
 2 Eternity Link TierraCast 94-3005-18  
 2 Large Shell Bead TierraCast 94-5679-61  
 2 Koi Fish Charm TierraCast 94-2306-01  
 4 small oval jumprings TierraCast 01-0016-09  
 12" Beadalon 0.015 Stringing wire  
 2 Buddha Bead TierraCast 94-5718-27

2 Sen Rings TierraCast 94-3017-12  
 4 Maldive Larin Charms TierraCast  
 2" 20 gauge gold Artistic Wire  
 2 Copper earwires TierraCast 90-1120-08  
 2 Silver Headpin TierraCast 01-0029-01  
 2 Gold Earwires TierraCast 90-3170-01  
 1 1" piece of small cable chain gold  
 2 2x2 crimp beads  
 2 Brass Oxidie Earwires TierraCast 90-1120-27  
 2 3" gold headpins

Continuation on next page

[“Quintet of Crystal Pearl Gems – Earrings”, page 2](#)

Instructions Quintet of Crystal Pearl Gems “Go Fish”

- STEP 1: Cut piece of chain into two equal pieces. Open one 4mm jump ring, slip on one end of chain and attach to one Koi fish charm. Repeat for the second side and set aside.
- STEP 2: Cut the 2“ piece of 20g wire into two equal pieces. Using one piece of wire, make a simple loop, slip on one Crystal Pearl art. 5810 4mm Crystal Red Coral Pearl and create a simple loop on the opposite side. Repeat for the second side using the remaining wire. Open one loop and attach to open end of chain from step 1, close loop. Repeat for second side. Set aside.
- STEP 3: Cut the beading wire in half. Secure one end and slip on 26 Crystal Pearls art. 5810 4mm Crystal Red Coral Pearl and one crimp bead. Thread the opposite wire into the crimp bead and crimp. Repeat for the second side. (Note: beaded strand should resemble a loop.)
- STEP 4: Open the remaining loop from step 2 and attach to the beaded loop from step 3 at the crimped portion and to one ear wire. Repeat for second side.

Instructions Quintet of Crystal Pearl Gems “Year of the Dragon”

- STEP 1: Cut the silver 20g wire into 18 one inch pieces.
- STEP 2: Using one piece from step one. Turn a simple loop. Slip on one Crystal Pearl art. 5810 4mm Crystal Dark Lapis Pearl and turn a simple loop on the second side. Repeat 17 times more. Eighteen links are made.
- STEP 3: Open one end on a link from step 2, slip on a second link and close loop, repeat once more. (Note: A chain link of three pearls has been created.)
- STEP 4: Repeat step 3 five more times.
- STEP 5: Open one loop end from step 4 and attach to one Maldive Larin Charm. Repeat three more times.
- STEP 6: Open one loop end from step 4 and attach to one Nisshu charm. Repeat one time more.
- STEP 7: Attach the chain links to the Zen Rings. Open the end loop of the Nisshu charmed link and attach to the center hole of the Zen Ring. Repeat for the second side.
- STEP 8: Open the end loop on the Maldive Larin charm link and attach to the outside hole of the Zen ring. Repeat once for the opposite side.
- STEP 9: Repeat step 8 for the second pair.
- STEP 10: Using one silver ear wire, slip on one Crystal Pearl art. 5810 4mm Crystal Dark Lapis Pearl. Turn a simple loop. Repeat for the second pair.
- STEP 11: Open the loop made in step 10 and attach to the top loop of the Zen ring. Repeat for the second pair.

"Quintet of Crystal Pearl Gems – Earrings", page 3

Instructions Quintet of Crystal Pearl Gems "Celtic Blue"

- STEP 1: Using one copper head pin, slip on one Crystal Pearl art. 5811 16 mm Crystal Turquoise Pearl and create simple loop. Repeat for second side.
- STEP 2: Open the loop on top of the pearl made in step 1 and attach to one eternity link. Repeat for second side.
- STEP 3: Using one copper ear wire, slip on one Crystal Pearl art. 5810 4 mm Crystal Turquoise Pearl and create a simple loop. Repeat for second side.
- STEP 4: Open the loop created from step 3 and attach to the eternity link. Repeat for second side.

Instructions Quintet of Crystal Pearl Gems "Serenity"

- STEP 1: Using one 3" head pin, load on one Crystal Pearl art. 5810 6 mm Crystal Ivory Pearl, (1) Buddha bead, one Crystal Pearl art. 5810 10 mm Crystal Ivory Pearl, (1) Bead art. 5040 8 mm Crystal Metallic Light Gold 2x and (1) Crystal Pearl art. 5811 16 mm Crystal Ivory Pearl. Create a wire-wrapped loop or simple loop. Repeat for second side.
- STEP 2: Using a brass ear wire, slip on one Bead art. 5328 4 mm Metallic Light Gold 2x. Turn a simple loop and repeat for the second side.
- STEP 3: Open the loop made in step 2 and add to the piece made in step 1. Repeat for second side.

Instructions Quintet of Crystal Pearl Gems "Pacific Jade"

- STEP 1: Use one silver head pin and slip on one Crystal Pearl art. 5810 10 mm Crystal Jade Pearl and one large shell bead. Turn a simple loop or wire-wrap. Repeat for second side.
- STEP 2: Using a silver ear wire, slip on one Bead art. 5328 4 mm Pacific Opal and turn a simple loop. Repeat for second side.
- STEP 3: Open the loop made in step 2 and add to the piece made in step 1. Repeat for second side.





MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"  
**CIRCULAR BLENDS**  
NECKLACE

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5000 (Round)	8 pcs.	10mm	Burgundy-Blue Zircon Blend	723
Beads	5040 (Briolette)	9 pcs.	8mm	Burgundy-Blue Zircon Blend	723
Pendants	6106	7 pcs.	22mm	Burgundy-Blue Zircon Blend	723

Supplies: 30" variegated Circular Chain  
7 10mm open jump rings TierraCast 01-0026-01

36" 24 gauge Artistic Wire

Instructions

- STEP 1: Open one jump ring and attach to one Swarovski Pendant art. 6106 22mm Burgundy-Blue Zircon Blend, close jump ring. Repeat six times more.
- STEP 2: Attach one pendant made in step 1 randomly onto the chain. Repeat six times more.
- STEP 3: Cut the 24g wire into 10 equal pieces.
- STEP 4: Using the Beads art. 5000 10mm Burgundy-Blue Zircon Blend and the Beads art. 5040 8mm Burgundy-Blue Zircon Blend, wire the beads to the inside wall of the large links. (Note: These Beads are randomly wired on so you choose which combination of beads you want to wire together: Single Beads art. 5000 10mm or one Bead art. 5000 10mm and one Bead art. 5040 8mm or three Beads art. 5040.)



CREATE  
YOUR STYLE  
with SWAROVSKI ELEMENTS

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# LUMINOUS NIGHTS IN MARRAKESH

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Sew-on Stones	3251	14 pcs.	18x9mm	Crystal Luminous Green	001 LUMG
Pendants	6656	1 pc.	39mm	Crystal Luminous Green	001 LUMG

Supplies: 6 medium quatrefoil TierraCast 94-3140-27  
48 open jump rings TierraCast 01-0020-27  
1 large tapered toggle TierraCast 94-6067-27

3 large quatrefoil TierraCast 94-3141-27  
4 small oval jump rings TierraCast 01-0016-27  
1 classic pinch bails TierraCast 94-5780-27

## Instructions

- STEP 1: Attach the pinch bail to the Pendant art. 6656 39mm Crystal Luminous Green. Open 2 jump rings and attach to the top end of the bail. Open two more jump rings and attach to the two previous jump rings and one large quatrefoil link.
- STEP 2: Working one side. Open 2 jump rings and attach to one Sew-on Stone art. 3251 18x9mm Crystal Luminous Green and attach to the large quatrefoil from step 1.
- STEP 3: Open 2 jump rings and attach to the second side of the space cut sew-on in step 2 and attach to one medium quatrefoil link.
- STEP 4: Open two jump rings and attach to one Sew-on Stone art. 3251 18x9mm Crystal Luminous Green and attach to the medium quatrefoil link from step 3.
- STEP 5: Open two jump rings and attach to the second side of the Swarovski Sew-on Stone and attach to one medium quatrefoil link.
- STEP 6: Open two jump rings and attach to one Sew-on Stone art. 3251 18x9mm Crystal Luminous Green and attach to the medium quatrefoil link from step 5.

[Continuation on next page](#)



"Luminous Nights in Marrakesh", page 2

- STEP 7: Open 2 jump rings and attach to the second side of the Swarovski Sew-on Stone and attach to one medium quatrefoil link.
- STEP 8: Open 2 jump rings and attach to one Sew-on Stone art. 3251 18x9mm Crystal Luminous Green and attach to the medium quatrefoil link from step 7.
- STEP 9: Open 2 jump rings and attach to the second side of the Swarovski Sew-on Stone and attach to one large quatrefoil link.
- STEP 10: Open 2 jump rings and attach to one Sew-on Stone art. 3251 18x9mm Crystal Luminous Green and attach to the large quatrefoil link from step 9.
- STEP 11: Open 2 jump rings and attach to the second side of the Swarovski Sew-on Stone from step 10 and attach to one Swarovski Sew-on Stone.
- STEP 12: Open 2 jump rings and attach to the second side of the Swarovski Sew-on Stone from step 11 and attach to one Swarovski Sew-on Stone.
- STEP 13: Open 2 small oval jump rings and attach to the second side of the Sew-on Stone art. 3251 18x9mm Crystal Luminous Green from step 12 and attach to one half of the toggle set.
- STEP 14: Working second side. Repeat step 2 through 12.
- STEP 15: Open 2 small oval jump rings and attach to the second side of the last space Swarovski Sew-on Stone and attach to the second half of the toggle set.

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# VERTICAL COLUMN BRACELET



## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5050	12 pcs.	14x10 mm	Crystal Vitrail Medium P	001 VM
Beads	5328 (XILION)	36 pcs.	4 mm	Jet	280
Beads	5535	4 pcs.	19x5 mm	Jet	280
Beads	5535	3 pcs.	23.5x5 mm	Crystal Silver Shade	001 SSHA

Supplies: 20" Beadalon 0.018 stringing Wire  
4 3mm crimp covers

4 2x2 crimp beads  
1 heirloom two loop toggle clasp TierraCast 94-6073-12

## Instructions

STEP 1: Cut wire in two 10" pieces.

STEP 2: Using the first piece of wire crimp to one side of the toggle clasp. Trim wire. Cover with crimp cover.

STEP 3: Slide on three Beads art. 5328, one Bead art. 5535 Jet, one Bead art. 5328, one Bead art. 5050, one Bead art. 5328, one Bead art. 5535 Crystal Silver Shade, one Bead art. 5328, one Bead art. 5050, one Bead art. 5328, one Bead art. 5535 Jet, one Bead art. 5328, one Bead art. 5050, one Bead art. 5328, one Bead art. 5535 Crystal Silver Shade, one Bead art. 5328, one Bead art. 5050, one Bead art. 5328, one Bead art. 5535 Jet, one Bead art. 5328, one Bead art. 5050, one Bead art. 5328, one Bead art. 5535 Crystal Silver Shade, one Bead art. 5328, one Bead art. 5050, one Bead art. 5328, one Bead art. 5535 Jet, 3 Beads art. 5328. Slip on one crimp bead and crimp to the corresponding loop on the other half of the toggle clasp. Trim wire. Cover with crimp cover.

STEP 4: Repeat steps 2 & 3 for the second strand.



MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# LUNAR ELLIPSE EARRINGS

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328	2 pcs.	4 mm	Crystal Red Magma	001 REDM
Beads	5535	2 pcs.	23.5x5mm	Crystal Red Magma	001 REDM
Pendants	6470	4 pcs.	32mm	Crystal Golden Shadow	001 GSHA

Supplies: 1 pair earwires TierraCast 90-1120-00  
3" 5mm medium oval link chain  
3" 20 gauge Artistic Wire

4 8mm open jump rings TierraCast 01-0020-01  
8 oval jump rings TierraCast 01-0018-01

## Instructions

- STEP 1: Cut the 20g wire into four 1" pieces. Make a simple loop onto one end of each of the four pieces.
- STEP 2: Take one piece of wire from step 1 and slip the open end into one hole of Bead art. 5535. Turn a simple loop Repeat once for the second hole.
- STEP 3: Repeat step 2 for the second pair.
- STEP 4: Open one 8mm round jump ring and attach to one Swarovski Pendant art. 6470 32mm. Repeat three times more. Set aside.
- STEP 5: Link 3 oval jump rings together and attach to one Swarovski Pendant from step 4. Repeat once.
- STEP 6: Attach one oval jump ring to one pendant from step 4. Repeat once.
- STEP 7: Open one loop on the Bead art. 5535 from step 2 and attach to one unit made in step 5. Open the second loop on the same side of the column bead and attach one unit from step 6.

[Continuation on next page](#)

[“Lunar Ellipse Earrings”, page 2](#)

STEP 8: Repeat step 7 for the second pair.

STEP 9: Cut the oval link chain into two pieces making sure there is an odd number of links total for each piece.

STEP 10: Open the opposite loops on the Bead art. 5535 from step 7 and attach each end of the same piece of chain to the two loops on the same side of the column bead.

STEP 11: Repeat step 10 for the second pair.

STEP 12: Using one silver ear wire, slip on one XILION Bead art. 5328 4 mm and turn a simple loop. Open the loop and attach to the center of the chain added in step 10.

STEP 13: Repeat step 12 for the second pair.

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# GEOMETRIC HARMONY NECKLACE

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328	6 pcs.	4 mm	Olivine	228
Beads	5601	6 pcs.	4 mm	Khaki	550
Beads	5601	4 pcs.	8 mm	Khaki	550
Pendants	6470	2 pcs.	32 mm	Olivine	228
Pendants	6470	2 pcs.	40 mm	Olivine	228

Supplies: 5 hammertone rectangles TierraCast 94-3097-61  
2 8mm open jump rings  
6" 10mm oval linked chain  
18" 3mm suede lace  
18" 22 gauge Artistic Wire

15 oval jump rings TierraCast 01-0018-01  
2 6mm open jump rings TierraCast 01-0025-01  
1 "S" clasp  
2 flat cord ends  
6" 20 gauge Artistic Wire

## Instructions

STEP 1: Open one 6mm jump ring and attach to one Pendant art. 6470 32mm Olivine from the SWAROVSKI ELEMENTS assortment. Open one oval jump ring and link to 6mm jump ring. Open second oval jump ring and link to one hammertone rectangle and oval jump ring previously added. Open third oval jump ring and attach to the top end of the hammertone rectangle. Repeat times one. Set aside.

STEP 2: Open one 8mm jump ring and attach to one Swarovski Pendant art. 6470 40mm Olivine. Open one oval jump ring and link to 8mm jump ring. Open second oval jump ring and link to one hammertone rectangle and oval jump ring previously added. Open third oval jump ring and attach to a second hammertone rectangle. Open fourth oval jump ring and attach to the top end of the hammertone rectangle. Set aside.

[Continuation on next page](#)

"Geometric Harmony Necklace", page 2

- STEP 3: Using 6" piece of 20 gauge wire perform a simple loop at one end. Slide on one Bead art. 5601 8mm Khaki, one Bead art. 5328 4mm Olivine, one unit from step one, one Bead art. 5328, one Bead art. 5601 8mm, one Bead art. 5328, the unit made from step 2, one Bead art. 5328, one Bead art. 5601 8mm, one Bead art. 5328, one unit from step 1, one Bead art. 5328, one Bead art. 5601 8mm. Perform simple loop on open end.
- STEP 4: Cut suede lace in half. Insert through simple loop in one side of unit made in step 3. Fold over suede by 1/2". Cut 3" of 22 gauge wire and perform a wrapped coil around the both pieces of suede lace in the direction toward the simple loop. Trim ends and tuck tails. Repeat for opposite side.
- STEP 5: Adjust to desired length and crimp one cord end on each side. Open two oval jump rings and attach one to each cord end.
- STEP 6: Open one end of the "S" clasp and slip through jump ring on cord end. Slide on one end of chain. Close down that end of the "S" clasp.
- STEP 7: Open one 8mm jump ring and attach to one Swarovski Pendant art. 6470 40mm Olivine. Open one oval jump ring and link to 8mm jump ring. Open second oval jump ring and link to one hammertone rectangle and oval jump ring previously added. Open third oval jump ring and attach to the top end of the Hammertone rectangle and the end of the chain.
- STEP 8: Cut remaining 22 gauge wire into 6 equal pieces. Using one piece turn a loop at one end of wire and flatten. Repeat 5 more times.
- STEP 9: Using one piece slide on one Bead art. 5601 4mm and turn a simple loop. Repeat 5 times.
- STEP 10: Open the loop from the unit above and attach to the last link of chain connected to the oval jump ring. Repeat 5 times.



MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# CRYSTAL WAVES AT MIDNIGHT NECKLACE

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328 (XILION)	90 pcs.	2.5 mm	Jet	280
Beads	5328 (XILION)	90 pcs.	3 mm	Jet	280
Beads	5328 (XILION)	81 pcs.	4 mm	Jet	280
Beads	5328 (XILION)	16 pcs.	4 mm	Sunflower	292
Beads	5525 (Wave)	16 pcs.	19 mm	Crystal	001
Beads	5525 (Wave)	8 pcs.	28 mm	Crystal	001

Supplies: 1 Vine Hook and Eye TierraCast 94-6106-12  
2 2x2 crimp beads

40" Beadalon 0.015 Stringing wire  
2 3 mm crimp covers

## Instructions

- STEP 1: Using the stringing wire crimp to one end of clasp set. Trim wire and attach with crimp cover.
- STEP 2: Slip on five Swarovski Beads art. 5328 2.5 mm Jet, five Beads art. 5328 3 mm Jet, nine Beads art. 5328 4 mm Jet, five Beads art. 5328 3 mm Jet, five Beads art. 5328 2.5 mm Jet, one Bead art. 5328 4 mm Sunflower, one Bead art. 5525 19 mm Crystal, one Bead art. 5525 28 mm Crystal, one Bead art. 5525 19 mm, and one Bead art. 5328 4 mm Sunflower. Repeat times 7.
- STEP 3: Add on five Beads art. 5328 2.5 mm Jet, five Beads art. 5328 3 mm Jet, nine Beads art. 5328 4 mm Jet, five Beads art. 5328 3 mm Jet, and five Beads art. 5328 2.5 mm Jet. Slip on one crimp bead and crimp to the second half of the clasp set. Trim wire and attach crimp cover.



CREATE  
YOUR STYLE  
with SWAROVSKI ELEMENTS

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# ROYAL WAVE NECKLACE

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5050 (Oval)	24 pcs.	14x10 mm	Jet	280
Beads	5328 (XILION)	63 pcs.	4 mm	Jet	280
Beads	5328 (XILION)	33 pcs.	2.5 mm	Jet	280
Beads	5328 (XILION)	6 pcs.	6 mm	Jet	280
Beads	5328 (XILION)	7 pcs.	4 mm	Sunflower	292
Pendants	6525 (Wave)	15 pcs.	19 mm	Crystal	001
Pendants	6525 (Wave)	1 pc.	28 mm	Crystal	001

Supplies: 18 oval jump rings TierraCast 01-0018-01  
1 Hammertone ellipse toggle TierraCast 94-6115-61  
1 20-25 mm bead cap with 8 links  
4 2x2 crimp beads  
1 5 yard spool 20 gauge Artistic Wire

1 lg Hammertone TierraCast 94-3087-61  
20" Beadalon stringing wire 0.015  
1 12-14 mm bead cap with 7 links  
4 3mm crimp covers  
6" 24 gauge Artistic Wire

[Continuation on next page](#)

["Royal Wave Necklace", page 2](#)

[Instructions tassel center dangle](#)

- STEP 1: Take the 6" piece of wire and slip on (1) oval jump ring. Bend the wire in half. Holding the wire take it through the underside of the small bead cap, then the underside of the large bead cap. Using both wires together, create a wire wrapped loop.
- STEP 2: Cut (6) 1" pieces of 20 gauge wire. Create a simple loop on one end of the wire. Repeat 5 times.
- STEP 3: Using (1) piece of wire from step 2, slide on (1) Bead art. 5328 6 mm Jet from the SWAROVSKI ELEMENTS assortment. Create a simple loop on the open side. Repeat 5 times. Using all of the pieces in this step create chained links.
- STEP 4: Cut (1) piece of ¾" wire and create a simple loop on one end. Slip on (1) Bead art. 5328 4 mm Jet. Create a simple loop on the open side. Open one of the loops just created and attach to the chained links in step 3.
- STEP 5: Open one jump ring and attach to (1) Swarovski Pendant art. 6525 28 mm Crystal and to the end of the chain (at the 4 mm side) created in step 4. Open the loop at the top of the 6 mm Bead unit and attach to the oval jump ring in step 1.

[Instructions tassel inner dangles](#)

- STEP 1: Open one oval jump ring and attach to (1) Swarovski Pendant art. 6525 19 mm Crystal. Repeat six times.
- STEP 2: Cut (49) ¾" pieces of 20 gauge wire. Create a simple loop on each piece. Take one piece of wire and slip on (1) Bead art. 5328 4 mm Jet and create a simple loop on the open end. Repeat 20 times.
- STEP 3: Take one piece of wire and slip on (1) Bead art. 5328 4 mm Sunflower and create a simple loop on the open side. Repeat 6 times.
- STEP 4: Using (1) wire from step 1, slip on (1) Bead art. 5328 3 mm Jet and create a simple loop on the open side. Repeat 20 times.
- STEP 5: To assemble chain dangles: attach together (1) 4 mm Jet unit, (1) 3 mm Jet unit, (1) 4 mm Jet unit, (1) 3 mm Jet unit, (1) 4 mm Jet unit, (1) 3 mm Jet unit, (1) 4 mm Sunflower unit, (1) Swarovski Pendant art. 6525 19 mm Crystal. Repeat 6 times more.
- STEP 6: Open the top of each chain link made in step 5 and attach to each loop on the small bead cap for a total of seven inner dangles.

["Royal Wave Necklace", page 3](#)

[Instructions tassel outer dangles](#)

- STEP 1: Open one oval jump ring and attach to (1) small wave pendant. Repeat six times
- STEP 2: Cut (32)  $\frac{3}{4}$ " pieces of 20 gauge wire. Create a simple loop on each piece. Using one piece of wire and slip on (1) Bead art. 5328 3 mm Jet and create a simple loop on the open end. Repeat 16 times. Using another piece of wire slip on (1) Bead art. 5328 4 mm Jet and create a simple loop on the open end. Repeat 16 times.
- STEP 3: To assemble chain dangles: attach together (1) 4 mm Jet unit, (1) 3 mm Jet unit, (1) 4 mm Jet unit, (1) 3 mm Jet unit and (1) Swarovski Pendant art. 6525 19mm Crystal. Repeat 7 times more.
- STEP 4: Open the top of each chain link made in step 3 and attach to each loop on the large bead cap for a total of eight dangles.

[Instructions necklace](#)

- STEP 1: Open (1) oval jump ring and slip on (1) Hammertone ring and attach to the wired loop made in step 1 of the center dangle instructions.
- STEP 2: Cut bead stringing wire into two equal parts.
- STEP 3: Using (1) piece of stringing wire, crimp to the Hammertone ring. Trim wire and attach crimp cover. String on (1) Bead art. 5328 4 mm Jet and (1) Bead art. 5050 14x10mm Jet and repeat 11 times more. Slip on one crimp bead and crimp to one half of toggle clasp. Trim wire and attach crimp cover.
- STEP 4: Repeat step 3 for second side.



MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"  
LEATHER WRAP GEMS  
BRACELET

Materials

SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Buttons	3024 (Dufflecoat)	1 pc.	23 mm	Crystal Tabac	001 TAB
Beads	5040 (Briolette)	1 pc.	6 mm	Sunflower	292
Beads	5328 (XILION)	1 pc.	4 mm	Denim Blue	266
Beads	5601 (Cube)	1 pc.	8 mm	Khaki	550
Crystal Pearls	5810	60 pcs.	6 mm	Crystal Dark Green Pearl	001 814

Supplies: 4' 1 mm leather

1 package carded silk (with needle attached) size 3

Instructions

- STEP 1: Fold leather evenly in half and slip through the Button art. 3024 23mm Crystal Tabac from the SWAROVSKI ELEMENTS assortment.
- STEP 2: Using the tail end of the silk tie silk onto both strands of the leather as close to the Swarovski Button as you can.
- STEP 3: Note: Keep leather side by side throughout the construction of the bracelet. As well keep the tension of the thread taught.
- STEP 4: With the needle exiting between the 2 strands of leather. Slip on one Crystal Pearl art. 5810 6mm Crystal Dark Green Pearl with the Pearl facing North to South to the leather. The needle will be exiting out of the top of the pearl. Wrap around the upper strand of the leather and put the needle back through the center of the leather strands and insert the needle through the Crystal Pearl again going from North to South with the thread exiting the bottom of the Crystal Pearl. Wrap the silk around the bottom strand of leather and having it come out the middle of the two pieces of leather. (Note: You are back to your starting point.)

Continuation on next page

"Leather Wrap Gems Bracelet", page 2

- STEP 5: While keeping tension on the thread against the leather attach on each subsequent Crystal Pearl in the same manner from step 4.
- STEP 6: When the last Crystal Pearl is added take the silk strand and knot it around both pieces of leather. Clip the thread to within 4" of the knot that was just made. Slip onto the tail one Swarovski Bead art. 5601 8mm Khaki, one Bead art. 5040 6mm Sunflower, and one Bead art. 5328 4mm Denim Blue. Make a double overhand knot to hold in the trio of SWAROVSKI ELEMENTS. Put a dab of cement onto the thread exiting the end of the knot.
- STEP 7: Keeping both leather tails together make an overhand knot 3/4" from the tail of the silk. Tighten knot. Clip the leather at an angle 1/2" from the knot.
- STEP 8: Using cement glue, Put a dab of glue on the silk where the tail exits at each end of the bracelet. Let dry overnight.
- STEP 9: Nip the tail off on the button side and nip the tail to within 1/4" of the knot holding in the trio of SWAROVSKI ELEMENTS.





CREATE  
YOUR STYLE  
with SWAROVSKI ELEMENTS

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# COLUMN BEAD BRIDAL SUITE NECKLACE & EARRINGS

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5534 (Column)	10 pcs.	14.5x5mm	Crystal	001
Beads	5534 (Column)	10 pcs.	19x5mm	Crystal	001
Beads	5534 (Column)	5 pcs.	23.5x5mm	Crystal	001
Crystal Pearls	5810	12 pcs.	3mm	Crystal White Pearl	001 650
Crystal Pearls	5810	20 pcs.	4mm	Crystal White Pearl	001 650
Crystal Pearls	5810	22 pcs.	6mm	Crystal White Pearl	001 650
Crystal Pearls	5821	2 pcs.	11x8mm	Crystal White Pearl	001 650

Supplies: 1 Hammertone Heart Toggle 94-6124-61  
1 pair earwires TierraCast 90-1120-00

2 oval jump rings TierraCast 01-0018-01  
1 spool 20 Gauge Artistic Wire

[Continuation on next page](#)

[“Column Bead Bridal Suite Necklace & Earrings”, page 2](#)

#### Earring Instructions

- STEP 1: Cut two pieces wire 2” long. Turn a loop and flatten on each piece. Slip on one Crystal Pearl art. 5821 11x8mm Crystal White Pearl from the SWAROVSKI ELEMENTS assortment. Create a simple loop. Repeat for second wire. Set aside.
- STEP 2: Cut two 3” pieces of wire and create a simple loop at one end of both pieces. Take one piece of wire and slip on one Crystal Pearl art. 5810 3mm Crystal White Pearl, one Bead art. 5534 14.5x5mm, Crystal Pearl art. 5810 3mm, one Bead art. 5534 19x5mm, one Crystal Pearl art. 5810 3mm, one Bead art. 5534 23.5x5mm, one Crystal Pearl art. 5810 3mm, one Bead art. 5534 19x5mm, one Crystal Pearl art. 5810 3mm, one Bead art. 5534 14.5x5mm, and one Crystal Pearl art. 5810 3mm. Create a simple loop at the open end. Repeat for second pair.
- STEP 3: Using one silver earwire slide on one Crystal Pearl art. 5810 4mm and turn a simple loop. Open loop just created and attach to one end of the unit from step 2. Repeat for second pair.
- STEP 4: Open loop created in step 1 and attach to opposite end of unit created in step 3. Repeat for second pair.

#### Necklace Instructions

- STEP 1: Cut three 3” pieces of wire and create a simple loop at one end of both pieces. Take one piece of wire and slip on one Crystal Pearl art. 5810 4mm Crystal White Pearl, one Bead art. 5534 14.5x5mm, one Crystal Pearl art. 5810 4mm, one medium column bead, one Crystal Pearl art. 5810 4mm, one Bead art. 5534 23.5x5mm, one Crystal Pearl art. 5810 4mm, one Bead art. 5534 19x5mm, one Crystal Pearl art. 5810 4mm, one Bead art. 5534 14.5x5mm, and one Crystal Pearl art. 5810. Create a simple loop at the open end. Repeat two more times. Set aside.
- STEP 2: Using wire cut 22 1” pieces of wire.
- STEP 3: Using one piece of wire create a simple loop, slip on one Crystal Pearl art. 5810 6mm Crystal White Pearl and create a simple loop on the open end. Repeat 21 times.
- STEP 4: To connect the SWAROVSKI ELEMENTS units from step 1, use one wired unit from step 3. Open each end and attach to the first and second SWAROVSKI ELEMENTS unit. Take another wired unit from step 3. Open each end and attach to the second and third SWAROVSKI ELEMENTS unit.
- STEP 5: To create the chain links, open one end of every remaining link and attach to the opposite side. Repeat 9 times to create one side of necklace.
- STEP 6: Repeat step 5 to create the opposite side of necklace.
- STEP 7: Open one oval jump ring, insert one half of toggle clasp and attach to the end of the chain links. Repeat for opposite side.

MINI PROJECT "INNOVATIONS SPRING/SUMMER 2013"

# EVOLUTION OF ROSE PEACH COLLAR

## Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5000 (Round)	50 pcs.	8 mm	Rose Peach	262
Beads	5040 (Briolette)	50 pcs.	8 mm	Rose Peach	262
Beads	5328 (XILION)	225 pcs.	4 mm	Rose Peach	262
Crystal Pearls	5810	100 pcs.	3 mm	Crystal Rose Peach Pearl	001 674
Crystal Pearls	5810	120 pcs.	4 mm	Crystal Rose Peach Pearl	001 674
Crystal Pearls	5810	50 pcs.	6 mm	Crystal Rose Peach Pearl	001 674
Crystal Pearls	5810	40 pcs.	8 mm	Crystal Rose Peach Pearl	001 674
Crystal Pearls	5810	6 pcs.	12mm	Crystal Rose Peach Pearl	001 674

Supplies: 2 Silver Headpin TierraCast 01-0029-01  
12 2x2 crimp beads  
132" Beadalon stringing wire 0.015

1 Large Tapered Toggle TierraCast 94-6067-12  
12 3mm crimp covers  
Scotch tape

## Instructions

- STEP 1: Cut stringing wire into 6 equal lengths of 22" each. Set aside
- STEP 2: Using a headpin add one Swarovski Bead art. 5328 4 mm Rose Peach and then one Crystal Pearl 12 mm Crystal Rose Peach Pearl. Wire wrap to close. Repeat five more times and set aside.
- STEP 3: Taking one piece of stringing wire tape off one end of the wire 2" down from the end. Using all the rose peach crystal shapes and sizes begin random stringing of the crystals for 8". For the next 6" string only Bead art. 5328 4 mm Rose Peach. And for the last 4" randomly string both Beads in Rose Peach and Crystal Rose Peach Pearls of all sizes and shapes. String on one crimp bead and then one of the Crystal Pearls 12 mm drops made in Step 2. Crimp to close. Add crimp cover. Repeat two more times.

[Continuation on next page](#)

"Evolution of Rose Peach Collar", page 2

- STEP 4: Taking one piece of stringing wire tape off one end of the wire 2" down from the end. Using all the Crystal Rose Peach Pearl shapes and sizes begin random stringing of the Crystal Pearls for 8". For the next 6" string only Crystal Pearls art. 5810 3 mm and 4 mm Crystal Rose Peach Pearls. And for the last 4" randomly string both Beads in Rose Peach and Crystal Rose Peach Pearls of all sizes and shapes. String on one crimp bead and then one of the Crystal Pearls 12 mm drops made in Step 2. Crimp to close. Add crimp cover. Repeat two more times.
- STEP 5: Using one string of set made in step 3 remove tape and sting on crimp bead. Using one side of toggle crimp to close. Add crimp cover. Repeat 2 more times.
- STEP 6: Using one string of set made in step 4 remove tape and sting on crimp bead. Using one side of toggle crimp to close. Add crimp cover. Repeat 2 more times.
- STEP 7: Taking both sides of jewelry piece and using center 6" sections of both sides as a guide complete and overhand knot to complete the piece.